## **OPERATING INSTRUCTIONS:**

- 1. Place inverter in a well ventilated area.
- 2. Ensure the inverter on/off switch is in the OFF position
- 3. Inverter is to be protected from moisture, direct heat and excessive dust.
- 4. Ensure battery is fully charged.
- 5. CLAMP CABLE: Attach 12V input cables to the inverter. Attach positive (red) spade terminal to the positive (+) screw terminal and the negative (black) spade terminal to the negative (-) screw terminal and tighten with a screwdriver.

  Attach positive (red) clamp to the positive (+) terminal of the battery. Attach negative (black) clamp to the negative (-) terminal of the battery.
- 6. WARNING: DO NOT CONNECT IN REVERSE
- 7. Connect appliance to inverter, ensure the appliance is in the OFF position.
- 8. Turn ON inverter.
- Turn ON appliance.

## TROUBLESHOOTING GUIDE:

PROBLEM	CAUSE	RESULT
No power light on inverter	<ul> <li>Fuse on vehicle blown</li> <li>Poor connection to vehicle</li> <li>Low battery voltage</li> <li>Fuse on inverter blown</li> </ul>	<ul> <li>Check fuses / replace</li> <li>Ensure connection is firm</li> <li>Ensure battery charged</li> <li>Replace fuse</li> </ul>
Appliance has no power	<ul> <li>Draw of appliance exceeds inverter capability</li> <li>Low battery voltage</li> <li>Temperature Overload</li> </ul>	<ul> <li>Do not exceed wattage of inverter</li> <li>Ensure battery charged</li> <li>Allow unit to cool</li> </ul>
	WARNING ALARMS	S
BI—BI—BI	Low Battery pre alarm	Inverter will cease to operate if continued use

## SPECIFICATIONS MAI-600P

MODEL NUMBER	MAI-600P	
Output waveform	Pure sine wave	
Output power continuous	600W	
Output peak	1200W	
Soft start	1	
Output overload cut-off	· · · · · · · · · · · · · · · · · · ·	
DC Input High Cut-Off	√ -	
DC Input low Cut-Off	√ .	
Short Circuit protection	1	
Auto restart	√	
Internal Cooling Fan	. 1	
Matson Antizap®	√	
Fuse/s	35A x 2	
Dimensions (LxWxH)	250 x 140 x 65mm	
Weight (kg)	1.42kg	
Input Voltage	11—15 Volts DC	
Output Voltage	240Volts AC +/- 5%	
Frequency	50Hz	
Efficiency	85%	
Low battery Alarm	10.5 +/- 0.5 Volts	
Low Battery Shutdown	9.5 +/- 0.5 Volts	
High Voltage Shutdown	15.5 +/- 0.5 Volts	
Thermal Shutdown	60 degrees C	
Standby Current Draw .	0.60Amp	